

Funnel-Style Polarimeter Tube

MQOPT011 | Features and requirements to define



1 Top filling access

Plan the approach to the expanded top opening.

2 Sample tube

Specify the sample tube and working amount.

3 End-window assemblies

Confirm end-window parts and mating details.

REFERENCE VALUES

Nominal path option

100 mm

Illustrative design example; not an actual customer requirement.

Not to scale. Product-reference rendering with annotations; use the agreed drawing for dimensional acceptance.